

# Accessory Mounting



## MOUNTING INSTRUCTIONS


Always start by attaching the included black plastic brackets where you want your shelf, hook, dot, or picture hanger to be placed on the acoustic panel.



The black plastic bracket can be inserted without the use of tools. You can, for example, use the end of a teaspoon to screw the bracket in. Of course, you can also use a flat screwdriver or another flat tool.

### Mounting SHELVES - SMALL and LARGE

Start by attaching the included black plastic brackets where you want your shelf to be placed on the acoustic panel. Then place the shelf onto the bracket and fasten it with the included round screws in the same color as your shelf. Max load per shelf: 15 kg



### Mounting HOOKS

Start by attaching the included black plastic brackets where you want your hook to be placed on the acoustic panel. Then place the hook onto the bracket and fasten it with the included round screws in the same color as your hook.



### Mounting DOT

Start by attaching the included black plastic brackets where you want your dot to be placed on the acoustic panel. Then insert the round fitting with a hole in the middle into your dot and screw it into the plastic bracket.



### Mounting PICTURE HANGER

Start by attaching the included black plastic brackets where you want your picture frame to be placed on the acoustic panel. Attach the round picture fitting, which has a screw in the middle, to the black plastic bracket and hang your picture.

