

FibroTech Acoustic Panels OPERATION & MAINTENANCE

Instructions

These are our recommendations and guidelines for installing, using and maintaining FibroTech Acoustic Panels. More information is available at www.fibrotech.co.uk



Before installation

You need the following tools to install FibroTech Acoustic Panels: Ladder, rule, electric screwdriver, FibroTech panel screws, circular saw, glue gun and spirit level.

Check the surface of the wall as it will determine the best possible installation method. If the surface is uneven, install the acoustic panels on shuttering.

Do not forget to check the quality of the panels before installation.

Installing panels

Adjust/cut the panels with a fine-toothed blade. Cut from the back of the panels. The panel can be cut crosswise or lengthwise. The polyester backing can be cut using a box cutter. If the backing becomes detached from the rods, reattach it using staples.

Attach it using FibroTech panel screws or FibroTech installation adhesive - or both.

Use/operation and maintenance

FibroTech Acoustic Panels usually do not require subsequent maintenance. However, we recommend cleaning, as with any other surface, as required. Use the brush nozzle of the vacuum cleaner or a soft brush/broom.

FibroTech Acoustic Panels can be used in all rooms, both on walls and ceilings. Use FibroTech UNIKA panels for wet rooms with a relative humidity of 55% or less.

We recommend our FibroTech LIGHT Acoustic Panels for decorating furniture, doors, fronts etc. as the panels are significantly thinner and more flexible.



Scan and see our installation film for acoustic panels.

